


Back wall for C40-15DR-CS

Back wall closed of double row tube

(suitable for both 40GP and 40HQ containers)




Parts List		
Code	Description	Qty
B1L	Side base plates at left	1
B1R	Side base plates at right	1
B2	Middle base plates	3
B3	Side standing legs	2
B4	Lower standing legs	3
B5	Middle standing legs	1
B6	Middle upper standing legs	1
B6L	The upper part of the left standing legs	1
B6R	The upper part of the right standing legs	1
B7	Middle horizontal tubes	6
B8	Side horizontal tubes	2
B9	Bottom tensioning tubes	2
B10	Added standing legs to suit HQ containers	5
B11	Small diagonal brace	14
B12	48 Clips	14
B13	U Clips	4
B14	Welding iron plate for No. B3	2
B15	Two-hole angle bracket	1
B16	Back cover	1
U1	Rope	1 bu1ndle
U2	Small ratchet with strap	42
U15	Plastic cap	8
U26	Stake pegs	20
S11	Carriage bolts M10*90	8
S17	Bolts M10*50	14
S18	Bolts M10*30	11


S19	Bolts M12*40	28
S30	Flange nut M10	19
S29	Flange nut M12	28
S35	Nut M10	14
S26	Flat washer M12	56
S25	Flat washer M10	28

Back wall assembly


According to above Figure to find out all spare parts for back wall, connect them together by use screw, make sure the spacing. There are stake pegs for base plates.



B1L x1pc




B1R x1pc




B2 x3pcs






U26 x20pcs



Front




Top





B10 x5pcs




S19 x10pcs



S29 x10pcs



S26 x20pcs





B7 x6pcs



B8 x2pcs



B9 x4pcs



S11 x8pcs




U15 x8pcs



S30 x8pcs



B13 x2pcs





B11 x14pcs



B12 x14pcs




S25 x28pcs



S17 x14pcs




S35 x14pcs




S18 x8pcs



S30 x8pcs



Find out the back cover(No.B16), Insert the PPR tube (No. B17) on the frame and use small ratchet (No. U2) with straps to tie down the cover and tube.



Adjust and tighten them once per month after assembly to make sure they work perfect.